

Installation Guide:

These wall sections are designed for installation under an existing header and between existing posts. They are not structural and will not support a roof. The top channel and one side receiving channel will be split lengthwise for ease of installation.

1. Install the base channel to the floor surface using lag screws or concrete anchors.
2. Install ½ of the top channel using lag screws.
3. Install the side receiving channels at both ends. One should be solid, the other cut in half, install only 1 half of the cut channel.
4. Install the 1st wall section starting at the end with the solid receiving channel and attach with self-tapping screws. Make sure not to bury the spline groove in the receiving channel
5. Install the rest of the wall sections with “H” mullions between adjoining walls.
6. After all walls are in place, install the remaining halves of the top and receiving channels using self-tapping screws.

PARTS DESCRIPTION

- A. Top & Bottom Channel
(top cut in half)
- B. Side Receiving Channels
(1 side cut in half)
- C. 1” x 2” Fully Screened
Wall Section
- D. “H” Mullion Channel

Gazebo Junction, Inc.

2627 Kaneville Ct.

Geneva, IL 60134

800-966-9261

ALUMINUM PORCH WALL INSTALLATION GUIDE

